

BEAM DRILL-ZONE CRITERIA

“No Drill Zone” for typical IT-beam and R-beam members - if other requirements are needed, request must be submitted to & approved by precast engineer with exact location and size of penetration.

No Drill Zone” Criteria:

1. No drilling for anchors in “no drill zones” below.
2. No use of low velocity powder activated fasteners in “no drill zones” below.

